

Installation Instructions
Type C Permanent / Removable Models
Type C: Models 300 / 306 / 600

Type C (Removable)

Step 1: With the unit fully opened and the permanent hinge up, slide the left housing half over the turn signal lever until it meets the steering column. Close the right half.

Step 2: Place the ignition bracket over the permanent hinge. Open the padlock and insert the shackle through the large opening between the flanges of the ignition bracket then close the lock.