

# Installation Instructions

## Type B Permanent Models

### Type B: Models P310 / P312 / P250

#### Type B (Permanent)

#### Tools Needed

3/16" Allen Wrench

3/8" Socket and Ratchet

**Step 1:** With the permanent hinge in the upright position, slide the left housing half (with the slot on the bottom) over the turn signal lever until it meets the column.

**Step 2:** Position the right housing half (with the tab on the bottom) on the right side of the steering column, then slide the tab into the slot on the left housing half. Swing the permanent hinge down over the upper tabs on the top of the housings.

**Step 3:** Insert the break-away screws into the center hole on the left side of the permanent hinge and on the bottom of the unit and finger tighten only.

**Step 4:** Make sure the entire unit fits snugly against the steering column. If the unit does not fit tightly, identify gaps, remove the unit and apply filler material to the inside of the unit where you noticed the gaps. Reinstall the unit.

**To permanently install the unit, proceed to Step 5 only after you are sure the unit fits properly. This step cannot be reversed, installation will be permanent.**

**Step 5:** Once the unit fits to your satisfaction, use a 3/16" Allen Wrench to tighten the black hinge bolt at the left side of the permanent hinge. Then use a small ratchet with a 3/8" socket to tighten the silver break-away screw. Tighten until the head of the screw breaks off. **The unit is now permanently installed and cannot be removed from the vehicle.**

**Step 6:** Place the ignition bracket over the permanent hinge. Open the padlock and insert the shackle through the large opening between the flanges of the ignition bracket then close the lock.