

**Installation Instructions**  
**Type C Permanent / Removable Models**  
**Type C: Models 300 / 306 / 600**

**Type C (Removable)**

**Step 1:** With the unit fully opened and the permanent hinge up, slide the left housing half over the turn signal lever until it meets the steering column. Close the right half.

**Step 2:** Place the ignition bracket over the permanent hinge. Open the padlock and insert the shackle through the large opening between the flanges of the ignition bracket then close the lock.